# How to Avoid Leaking Fittings in Your Shipment

Buyer action checklist — print & use

## Checklist

1. Lock fitting brand/model in the BOM (no silent substitution).
2. Require 500 PSI hydrostatic test records per production lot.
3. Pull samples for a 24-hour standing pressure test before shipment.
4. Inspect O-rings on incoming fittings: no nicks, no flattening, correct size.
5. Verify tubing insertion depth marks are used on the assembly line.
6. Check packing: individual bags, carton dividers, pallet wrap against vibration.