How to QC RO Membranes Before Shipment

Buyer action checklist — print & use

Checklist

1. Collect batch salt-rejection test reports from the membrane supplier.
2. Verify date codes and dry/wet status against the packing list.
3. Inspect packaging integrity (punctured vacuum packs = suspect).
4. Pull samples per AQL and run TDS rejection tests on a test rig.
5. Confirm brand and model match the approved BOM — no silent substitutions.
6. Record lot numbers for traceability in case of field failures.