# RO Booster Pump

QC & buyer checklist — print & use

## Checklist

1. Always match pump class to membrane GPD — this is the #1 sizing mistake in OEM specs.
2. QC: run pump 30+ min; check overheating and pressure stability.
3. Ask for the pump's pressure curve, not just max pressure.