TDS (Total Dissolved Solids)

QC & buyer checklist — print & use

Checklist

1. Ship a calibrated TDS pen with samples — turns a spec into a 10-second buyer demo.
2. Define a pass/fail TDS threshold in the QC protocol (e.g., product ≤50 ppm at 25°C).
3. TDS alone doesn't prove safety — read it together with system certifications.